

User Manual

#### **Box Contents**

- (1) 10" Underground subwoofer
- (4) Satellite speakers (PRO)
- (6) Satellite speakers (PRO+)
- (4-6) Satellite speaker ground stakes
- (16) Silicone filled wire nuts

### Description

This system is designed to work well with most two-channel receivers or amplifiers, and will support up to six (6) satellite speakers and one (1) subwoofer. Four satellite speakers and one subwoofer are included with the PRO system. The system can be expanded by adding one additional pair of satellite speakers UltraScape Pro+



#### Installation Recommendations

The satellite speakers & subwoofer should be placed evenly so the sound will be distributed throughout your landscape area. For best results, plan the exact locations of each speaker along with the direct burial wire prior to digging. See diagram #1 on page 2.

TruAudio recommends that the satellite speakers be placed 6–8 feet apart, and no more than 10 feet for the best listening experience. An example of a landscape audio layout is shown on page 2. The ideal position for the subwoofer is in the center of the satellite speaker arrangement; bass response is enhanced if placed next to a wall or solid surface.


Speaker Wire Recommendations	Maximum Wire Length (feet)	Recommended Gauge
Always use multi-strand two or four conductor direct burial wire designed for speaker connections to the receiver or amplifier. Use this chart to select the minimum wire gauge for the length of the run.	100	18
	150	16
	250	14
	400	12c
	600	10





# Sample Ultrascape Pro Landscape Layout.

### Diagram 1




# **Wiring Diagram**

The satellite speakers and subwoofer should be connected in two parallel wire runs and buried in a single trench. The UltraScapePro is designed for speakers to be evenly divided between two wire runs with the subwoofer connected to both right and left. Below is a recommended connection.

Use only the waterproof wire nuts that came with your speakers. This will assure that no water will get in the connection.


The subwoofer has a dual voice coil with two sets of connections: one for the right channel, and one for the left. Make sure that the positive (+) is connected to the positive (+)and the negative (-) is connected to the negative (-). Continue connecting the speakers independently to the right and left channels.

Bundle all three of the right channel positive (+) wires from the first speaker, and wire the remaining speakers together as noted here. Then, do the same for the left channel, negative (-) wires. Run the wires to the next speaker and connect them the same way.










#### Installation

TruAudio recommends starting by digging a hole for the subwoofer (sizes noted below), which may be mounted vertically or horizontally. If mounted horizontally, the hole would need to be approximately 15" wide  $\times$  30" long  $\times$  17"– 19" deep. If mounted vertically, the hold would need to be approximately 15" wide  $\times$  15" long  $\times$  22"– 24" deep. This will leave approximately 6"– 8" of the subwoofer port tube and cap above the ground after the installation.

You must add 1"– 2" of gravel at the bottom of the hole to facilitate drainage around the base of the unit. If you add a layer of gravel, dig the hole 1"– 2" deeper to accommodate it.










# Subwoofer





# Satellite Speaker

Speaker Type: 2-way outdoor landscape speaker Woofer: 4" waterproof cone with rubber surround Tweeter: 0.75" marine grade PEI Power: 75 watts Minimum Power: 20 watts Impedance 16Ω Freq Response: 80 - 20K Hz (+/-3 dB) Sensitivity: 87 dB @ 1w/1m Grill Type: Aluminum Dimensions: Diameter: 5", Length: 7", Height: 7.7"



**ULTRAPRO-BASE:** Satellite Speaker Surface Mount

SoundVision Technologies dba TRUAUDIO

## **OUTDOOR SPEAKERS and SUBWOOFERS PRODUCT WARRANTY**

All outdoor speakers and subwoofers have a limited 5 year warranty. The warranty extends only to the original purchaser of the product and not to any subsequent owner. TRUAUDIO's obligation under these warranties is limited to repairing or replacing any component found defective in material or workmanship under normal conditions of use with an equal and/or current product. These warranties shall not apply to products which have been abused, modified, or disassembled. Products to be repaired or returned under this warranty must be returned to the factory through an authorized TruAudio dealer with all transportation and insurance charges prepaid.

It is the policy of TRUAUDIO to continuously incorporate improvements into our products. All specifications are subject to change without notice. If you have any questions regarding this or any other TRUAUDIO products, please visit www.TruAudio.com or contact us:

Office: 1-888-858-1555, Monday-Friday 7 am - 6 pm MST.

Email: CustomerService@truaudio.com

TruAudio 198 N Old Highway 91 Hurricane, UT 84737 USA

